


# Activejet®

## AE-664Bk

Tusz do drukarki Epson zastępuje tusz Epson T6641



<b>Kolor</b>	Czarny
<b>Technologia druku</b>	Druk atramentowy
<b>Rodzaj naboju z atramentem</b>	Wysoka (XL) wydajność
<b>Ilość czarnych wkładów atramentowych</b>	1
<b>Pasuje do urządzeń</b>	Epson
<b>Ilość</b>	1 szt.
<b>Objętość czarnego tuszu na stronę</b>	100 ml
<b>Eksploatacja kompatybilna</b>	Epson T6641
<b>Model</b>	Zamiennik
<b>Rodzaj atramentu</b>	Atrament barwnikowy
<b>Rodzaj opakowania</b>	Pudełko
<b>Klasa</b>	A+
<b>Technologia</b>	New
<b>Wersja</b>	Supreme
<b>Zastępuje</b>	Epson T6641
<b>Rodzaj dostawy</b>	Jednopak

<b>Certyfikaty</b>	ISO 9001, ISO 14001, ISO 27001, ISO 28000, TÜV Rheinland (ISO/IEC 19752, ISO/IEC 19798), CE
<b>Opis blokowy</b>	Activejet Tusz
<b>Grupa</b>	Gold
<b>Zastosowanie</b>	Wydruki profesjonalne - zdjęcia, katalogi, prezentacje, oferty, dyplomy, zaproszenia, ulotki
<b>Rodzaj czarnego tuszu</b>	Atrament barwnikowy
<b>Piktogram(y) zagrożenia</b>	GHS07: Substancje drażniące
<b>Piktogram(y) zagrożenia</b>	GHS09: Substancje szkodliwe dla środowiska
<b>Ostrzeżenia</b>	Unikać kontaktu ze skórą i oczami.
<b>Ostrzeżenia</b>	Przechowywać z dala od dzieci.
<b>Ostrzeżenia</b>	Nie wyrzucać do zwykłego śmietnika, specjalna utylizacja wymagana.
<b>EAN</b>	5901443110651
<b>Kompatybilność</b>	Epson Ecotank L100, Epson Ecotank L101, Epson Ecotank L110, Epson Ecotank L111, Epson Ecotank L120, Epson Ecotank L130, Epson Ecotank L200, Epson Ecotank L201, Epson Ecotank L210, Epson Ecotank L211, Epson Ecotank L220, Epson Ecotank L300, Epson Ecotank L301, Epson Ecotank L303, Epson Ecotank L310, Epson Ecotank L313, Epson Ecotank L350, Epson Ecotank L351, Epson Ecotank L353, Epson Ecotank L355, Epson Ecotank L358, Epson Ecotank L360, Epson Ecotank L363, Epson Ecotank L365, Epson Ecotank L455, Epson Ecotank L550, Epson Ecotank L551, Epson Ecotank L555, Epson Ecotank L565, Epson Ecotank L655, Epson Ecotank L800, Epson Ecotank L801, Epson Ecotank L810, Epson Ecotank L850, Epson Ecotank L1300, Epson Ecotank L1800, Epson Ecotank L3060, Epson Ecotank L361, Epson Ecotank L375, Epson Ecotank L380, Epson Ecotank L382, Epson Ecotank L383, Epson Ecotank L385, Epson Ecotank L386, Epson Ecotank L395, Epson Ecotank L396, Epson Ecotank L405, Epson Ecotank L475, Epson Ecotank L485, Epson Ecotank L486, Epson Ecotank L495, Epson Ecotank L575, Epson Ecotank L3050, Epson Ecotank L3070, Epson Ecotank ET-2500, Epson Ecotank ET-2550, Epson Ecotank ET-2600, Epson Ecotank ET-2610, Epson Ecotank ET-2650, Epson Ecotank ET-4500, Epson Ecotank ET-14000, Epson Ecotank L121